## **DOT RAD shipments**:

Container IDs: SRRU002075 and SRRU002046 Required:

- 1. NRC 540/541- Generator shipper to sign/date Form 540, Section 10
- 2. Driver to sign/date Form 540, section 6 also fill in "shipping date"
- 3. Rad Tech or Driver to add (4) Class 7 Radioactive placards to the Intermodal
- 4. Rad Tech to place "RADIOACTIVE-LSA" marking on each long side of intermodal
- 5. Rad Tech to place small labels with container info on each long side of intermodal
- 6. Driver to sign acknowledgement of "Instructions to Carrier for Exclusive Use Shipment Controls"
- 7. Rad Tech Perform truck radiological survey after intermodal is loaded on the truck

## **Non-DOT shipments**:

Container IDs: SRRU002025, SRRU002036 and SRRU002068 Required:

- 1. NRC 540/541- Generator shipper to sign/date Form 540, Section 10
- 2. Driver to sign/date Form 540, section 6 also fill in "shipping date"
- 3. Driver to place small labels with container info on each long side of intermodal